



Thomas

COUP



Teller 21 / 28 / 33 cm
Plate

8,00 € / 13,50 € / 24,50 €



Teller oval 19 / 28 cm
Plate oval

13,50 € / 26,50 €



Suppenteller 22 cm
Plate deep

11,00 €



Gourmetteller tief 17 / 28 cm
Gourmet plate deep

8,50 € / 17,00 €



Suppentasse 2-tlg.
Creamsoup cup & saucer

20,50 €



Schüssel hoch 12 / 20 cm
Bowl tall

8,00 € / 28,00 €



Schüssel 15 / 20 / 27 cm
Bowl

10,00 € / 19,00 € / 43,50 €



Platte oval 42 cm
Platter oval

61,00 €



Saucière
Sauce-boat

21,50 €



Espressotasse 2-tlg. / 0,09 l
Espresso cup & saucer

8,50 €



Kaffeetasse 2-tlg. / 0,21 l
Cup & saucer 4 tall

12,50 €



Tee-/Cappuccinotasse 2-tlg. / 0,29 l
Tea-/Cappuccino cup & saucer

13,50 €



Becher 0,36 l
Mug

11,00 €



Untertasse oval 19 cm
Saucer oval

13,50 €



Krug 0,23 l / 0,76 l
Jug

11,00 € / 22,50 €



Zuckerdose mit Einschnitt / 0,28 l
Sugar box with indentation

12,00 €



Kaffeekanne klein 0,30 l
Coffeepot small

22,50 €



Teekanne 0,40 l / 1,30 l
Teapot

22,50 € / 72,50 €



Eierbecher mit Ablage
Egg cup with deposit

8,50 €